



## Software Update Instructions for GS2 1800 Display

---

*NOTE: These instructions do not apply to the first software update (version 2.0.554). See the special instructions to update to version 2.0.554.*

1. Go to [http://stellarsupport.deere.com/en\\_US/support/1800Update.html](http://stellarsupport.deere.com/en_US/support/1800Update.html)
2. Click on the **Download 1800 Software** button to download and install the version of GS2 LiveUpdate that supports the GS2 1800 Display along with the 2100 and 2600 Displays.
3. Run GS2 LiveUpdate once it is installed.
4. Follow the prompts in GS2 LiveUpdate, download the latest software update, and copy the software update to a USB storage device.
5. With the display ON, insert the USB device into the display. The system will show a screen prompting operator to reprogram display.
6. Follow the prompts on the display. Note that the display will reboot itself during reprogramming.

**DO NOT remove switched power, unswitched power, or USB stick while reprogramming.**

7. Once the update is complete, a message with a green check mark will appear.