


# Auto Unload PC Card

If Setup was completed prior to working in the field and those choices were used in the GreenStar Display, the Auto Unload feature can be used.

Auto Unload will unload all of the data on the card at once. All data within the same field will be merged together automatically.

If there are no Undefined or Unknown selections, all of the data will automatically be unloaded into JDOffice. If one is found, the unloading for that unit will be terminated, and the automatic unloading for the next unit will continue.

1. From the **File** menu, select **Auto Unload PC Card**.
2. A warning message will alert you that you are about to auto unload your PC Card.
3. Click **Yes** to continue the auto unload; click **No** to terminate the unload.



After the unload process completes, a message will alert you to the number of files that were unloaded - and the number that could not be unloaded due to incomplete data.

To finish unloading the card you will have to manually unload the PC card (see the Manually Unload the PC Card section).

## Manually Unload the PC Card

The Unload PC Card window lists all of the data files that were saved by the Mobile Processor during field operations.


1. From the **File** menu, select **Unload PC Card**.
2. In **Client**, select whose data you want to unload.

**NOTE:** If you have a single client version, there will always be just one name listed.

3. In **Farm**, select the farm that you want to unload data for.

**NOTE:** Fields for that farm will appear in the window.

4. In the list of field files, select a field to unload.



**NOTE:** In *Show data files*, select the type of files you would like to view:

Unprocessed only – Files on the PC card that have not been unloaded into JDOoffice.

Processed and unprocessed – Files on the PC card that have been unloaded into JDOoffice and files that have not been unloaded into JDOoffice.

To select all files for a particular field with the same crop, place a check in the “*Unload all data files for the selected field and type*”.

To view only certain types of files (Harvest Log Data, Boundary Log Data, and Document Log Data), select the type of data you would like to view. To view all data select “*All GreenStar Data*”.

5. Click **Unload**.

**NOTE:** If there are any undefined or unknown items (i.e. Farm, Field, Variety, etc.), the Edit Data window will appear (see the Edit Data Files section).

# Edit Data Files

If you have data files to edit or if they could not be auto unloaded, follow the below steps to define or correct the files.

1. In the Unload PC Card Window, click on the field name of the file(s) you want to edit.

2. Click **Edit**

3. In the Edit Data Files window, you can change the Farm, Field, etc. or create a new Farm, Field, etc.



**NOTE:** Any item(s) in **RED** need to be defined.

4. To define an item, click on the entry in red in the Data to Edit window


5. Once the item in red is selected, the window below will populate with the individual file(s).

6. Select the invalid or unknown file (i.e. (Invalid) Unknown Variety 9404)

**NOTE:** To view where this file is located on the map, select the invalid or unknown file and click on the Preview button. The file area and location will be shown highlighted on the map.



7. Select the **Edit** button. This will display the Edit Entry window.



**NOTE:** This window may change depending on the invalid or unknown item selected.

8. Select the correct item in the *Changed* column. Use the drop down arrow for more selections.

9. Click on **Change** or **Change All**


**NOTE:** *Change* - will only change the file you selected.  
*Change All* - will change all the files with the same invalid or unknown file name.

10. Once all the changes have been made to the field and all the items are in defined (in black text), click **Unload**.

## Tips and Troubleshooting for Unloading

### Issue:


When I attempt to unload, JDOffice cannot access my PC data card. I receive the following message:



### Solution:

Check to make sure your PC data card is in the card drive. If you PC data card in is in the drive, you may need to change your drive letter setting in JDOffice.

1. Within JDOffice, open the **File** menu, select **Preferences**.
2. Under the General tab, change your drive letter setting to the correct PC card drive.



**NOTE:** You can check the drive letter of you PC card by opening *My Computer* and viewing the drive letter of your pc data card.

3. Select **OK**


## Issue:

When I attempt to unload my pc data card, no files show in the Unload PC Card window. I also receive the following message.



## Solution:

1. Within JDOffice, open the **File** menu, select **Preferences**.
2. Under the Processing tab, uncheck "Show files in Unload Chooser exclusively for current client".
3. Select **OK**.



## Issue:

Can I view more information about the file in the Unload PC Card window?

## Solution:

To view more information about the file in the Unload PC Card window, use the buttons to the right of the Farm name (circled in red).

